



1016 Windward Ridge Parkway
Alpharetta GA 30005

Office: 770-643-8501
Fax: 770-643-8820
www.crystaltek.us.com

How To Use New Adhesive-Off

CrystalTek's Reformulated ADHESIVE-OFF is among a NEW technology family of patent pending products from CrystalTek's continuing research for powerful green solutions. Ready to use Ultra Adhesive-Off is designed to quickly remove pressure sensitive adhesive, grease/asphalt/tar smears, paint overspray, printing inks, and gum from multiple substrates: metal, glass, canvas, FRP, gel coat, fiberglass, etc. Ultra Adhesive-Off is a commercial grade product. Its non-flammable waterborne formula and new mild scent are widely preferred over the strong citrus odor and flammable nature of competing products, especially for indoor use. Contains no terpenes, caustics, acids, or known carcinogens. Do not soak carpet because it will affect the adhesive backing!

Step by Step

1. SHAKE WELL - Thoroughly drench dry adhesive:
 - *Spraying preferred, but a product soaked cloth works fine.*
 - *Works on pressure sensitive adhesives (water and solvent based acrylics)*
2. Allow about 3-5 minutes dwell time.
 - *Works best over 50 degrees F.*
 - *Product may dry off quickly if used in hot-dry weather. Re-soak as needed.*
3. Pressure wash, scrape, or wipe off.
 - *Depending on the size of the job, different removal methods can be used. For BIG jobs, a pressure washer or power hose works well. For medium jobs, scrape from bottom to top. For small jobs, wipe off with a paper towel or other clean cloth. A scrub brush works great around rivets, etc.*
4. Re-apply as needed.
 - *Thick layers of adhesive may require multiple applications for full removal.*
5. Rinse with water to prepare surface for new application
 - *No oily residue so cleanup is quick & easy*

